

1. Lock Initialization:

Connect two wires together,

Push the reset button (all the previous ibutton key and coding are invalid now)

2. Code Initialization

Push the reset button, all the code resets to "123456"

3. Set/Change Master Code

* --123456(or present master code)-----#--- * ---New master code---#

Note: one master code for each lock. 1-8 digits

4. Set master IB key

*, master code, #, *, touch ib card, group number(reserves "0000"), #

5. Set user ib card

*, touch master ib card (or *, master code, #), *, touch Ib card, group number, #

Group number is 1-4 digits

6. Set or Change combination with IB card

*, touch ib card, old combination (preset "123456"), #, new code, #

Note: Combination code is 1-6 digits

7. Cancel combination code(use ib card only)

*, touch ib card, old combination code, #, #

To set combination code back to ib card:

*, touch ib card, enter code, #

8. Set "code only"

*, master ib card (or * master code, #), *, #, group number, #

Note: first time setting, code is "123456"

9. Set/change "code only" function

*, group number, *, 123456 or old code, #, new code, #

10. Terminate ib card/code only

method 1: *, touch master card(or *, master code, #), #, touch ib card

method 2(use group number)

*, master card(or *, master code, #), #, group number, #

11. Terminate all ib card and code

*, master card(or *, master code, #), #, *, *, *, *, *, *, #

12. set passage mode:

unlock, *

in this mode, only "#" ...?

13. end passage mode:#, #, #