


Last update 06/25/2012

Disable E4 inside Lock Push Button:


New Style Eternity 4:



Disconnect Orange wire from connector.

Disable E4 inside Lock Push Button:

Old style Eternity 4:



Disconnect Blue wire from connector.