

## 4003-B2 Instructions

1. **Set program Key**-Key used to set master key. (Back up Emergency key)
  - A. Push the reset button on the back of the keypad. (Three beeps)
  - B. Touch a iButton key to the reader (three quick beeps)
  
2. **Set Master Key**-Key used to set permanent codes. (Emergency)
  - A. Touch the Program key to the reader twice (led flashing, lock unlocked)
  - B. While led is flashing touch another iButton key to the reader (one beep)
  
3. **Set Permanent code**- Permanent codes are set for only one user, and the lock will automatically lock behind the user. (4-second delay). Requires the use of master key to assign permanent code.
  - A. The Switches on the back of the keypad must be S1 Down and S2 up (up being the top of the keypad)
  - B. Touch master key to the reader twice (led flashing)
  - C. Punch in the permanent code while led is flashing, followed by the # sign.
  
4. **Set temporary code**- Mode used that lets the user set a unique locker code, while they are at the gym. When the first user leaves a second user can enter his unique code, which is kept until, that user leaves.
  - A. The Switches on the back of the keypad must be S1 up and S2 up (up being the top of the keypad)
  - B. Push in any code.
  
5. **Set guest iButton Key**- This is a key that is assigned to for a long-term user like the permanent code and requires the use of the master key to assign guest key.
  - A. The Switches on the back of the keypad must be S1 down and S2 down (up being the top of the keypad)
  - B. Touch master key to the reader twice (led flashing)
  - C. Touch the guest key to the reader.